

## Reviewing Mailbox's Password for DC 451 / 551 / 706 / 606 / 506

### Creating Mailbox

- Touch Press [**Settings / Meter Check**]
- Touch [**Store / Modify**]
- Select [**Mailbox – Create / Delete**]
- Select Mailbox number (001 – 200)
- Touch [**Create / Delete**]
- Input mailbox password (must be 4 digit)
- Touch [**Confirm**]
- Touch [**Enter / Change Name**]
- Input user name
- Touch [**Save**]
- Touch [**Close**] (3 times to exit to the main menu)

### To Check Mailbox's password

- Press '0' and 'Start' together
- Enter password **6789**
- Touch [**Confirm**]
- Touch [**Chain Link**]
- Enter chain no.s as **820**
- Touch [**Link no.s**]
- Enter link no.s as **761**
- Touch [**Read / Confirm**]
- Touch [**New Value**]
- Input value to be **1**
- Press [**Start**]
- Press [**Close**]
- Press [**Exit**]

Note: Reset the value to '0' so as user will not be able to view the others Mailbox's password.

### **Deleting Mailbox**

- Touch Press [**Settings / Meter Check**]
- Touch [**Store / Modify**]
- Select [**Mailbox – Create / Delete**]
- Select Mailbox number to be deleted
- Touch [**Create / Delete**]
- Enter password
- Press [**Confirm**]
- Press [**Delete Mailbox**]
- Press [**Yes**] to confirm
- Touch [**Close**] (3 times to exit to the main menu)