

Auditron for DC 451 / 551 / 706 / 606 / 506

To Create Password

- Touch **[Setting / Meter Check]**
- Touch **[Auditron Admin. Mode]**
- Enter Access Number **xxxxx**
- Touch **[Confirm]**
- Touch **[Create / Modify A/cs]**
- Touch **[▲]** account no.s #100 – 399
Start from account nos. #101 or the next available no.s
- Touch **[Key in Password]**
- Enter password xxxxx (max 12 digits)
- Touch **[Enter]**
- Touch **[Close]**
- Repeat * or
- Touch **[Close]** then **[Exit Auditron]**

To Review Accounts

- Touch **[Setting / Meter Check]**
- Touch **[Auditron Admin. Mode]**
- Enter Access Number **xxxxx**
- Touch **[Confirm]**
- Touch **[Review Accounts]**
- Touch **[▲]** (to scroll through individuals copy volume)
- Touch **[Close]**
- Touch **[Exit Auditron]**

To Reset Copy Volume

- In Auditron mode
- Touch **[Auditron Setup]**
- Touch **[All Copy Volumes]**
- Touch **[Yes]**
- Touch **[Close]**
- Touch **[Exit Auditron]**